


NOTE: CONSTRUCTION JOINT KEY OMITTED FOR CLARITY.



SECTION NEAR INTERIOR WING (UPSTREAM SHOWN)

GENERAL NOTES:
ALL DIMENSIONS SHOWN ARE IN INCH UNLESS OTHERWISE NOTED.
JI BARS MAY BE BENT IN FIELD OR SHOP.
MINIMUM CLEARANCE TO REINFORCING STEEL SHALL BE 1-1/2"
UNLESS OTHERWISE SHOWN,
FOR DIMENSIONS AND 51ZE AND SPACING OF REINFORCING STEEL.
SEE STANDARD SHEET TOOLS. TO:
SHEET TOOLS. JT. REINFORCEMENT IN WINGS. SEE STANDARD
SHEET TOOLS. JT.